

PRX-2000 Installation Template

RIGHT HAND

LEFT HAND

Edge of door for
2-3/4" backset

Edge of door for
2-3/8" backset

1/4" Dia.
Thru hole x2

Edge of door for
2-3/4" backset

3/8" Dia.
Thru hole x1

Edge of door for
2-3/8" backset

3/8" Dia.
1/4" deep x2

7/8" x 1-7/8"
Thru hole x1

1" x 2-1/4"

2-1/8" Dia
Thru hole x1

1" x 2-1/4"

1" Dia

1" Dia

Center line of
door thickness

Center line of
door thickness

2-3/8"
Backset

2-3/8"
Backset

2-3/4"
Backset

2-3/4"
Backset

